




GPP-360

Gas piston height adjustable pedestal table



Assembly Instructions:

- 1) Attach the X-base to the Column using the supplied Hex Head Bolt. Use a 3/4" socket wrench to tighten nut.
- 2) If Levelers or Casters are not installed, then thread supplied Levelers or Casters into the bottom of the X-Base.
- 3) Attach tabletop to mounting plate using the supplied Pan Head Screws in the pre-drilled holes.

Operating Instructions: To raise table, gently push down on Table Top and activate Lever. Allow table to rise under own power. Release Lever, making sure pin is engaged in locking holes. To lower table: Gently push down on table top and activate Lever. Release lever, making sure pin is engaged in locking hole.

Care and Maintenance: Clean the Table Top, Pedestal, and X-base with a soft cloth and gentle, non-abrasive cleaner for fine furniture.